RS-28 & 71 & 39 Reflex Sight

User Manual

Operating Instructions

For optimum performance and to prevent damage to this precision instrument, carefully follow all instructions.

Contents

Specification 3
Inside the box 3
RS-28 Digram 4
RS-71 Digram 5
How to use 6
Zeroing 8
Elevation & Windage Adjustment . . 8
Notice 9
Warranty 9
Contact 9



(RS-28)



(RS-**39**)

Specification

Magnification	1x
Objective aperture	33mm
Field of View	15.8@ 100m
Windage/Elevation Click Value	1 MOA per Click
Adj. Range	+/- 30 MOA
Eye Relief	Unlimited
Length	82mm
Battery	1xCR2032
Weight	4 oz
Size	3.2″ x 1.5″ x 2.1″

Inside the box

1 x 4 Reticles Reflex Sight
1 x Rubber lens Cap Cover
1 x CR 2032 Battery
1 x Cleaning Cloth
2 x Wrenches

RS-28 Digram



RS-71 Digram



RS-39 Digram



How To Use?

1. Install the battery

Place the CR2032 battery into the battery compartment.



2. Turn on the reflex sight

Rotate the brightness setting dial to the right setting. The reticle will be reflexed on the lens.

Turn to "R" or "G" to power off.



3. Select the reticle

Pull the reticle selector knob. There are 4 reticle patterns to choose.





Zeroing

Select the reticle you desire by turning the reticle selector knob and set your intensity at the best position. With the sight mounted, rest the gun on a solid support and aim at a target 50 to 100 yards away. Test shots should be done in the same conditions to achieve maximum accuracy for adjustment, for which the use of firm rest for firing and same type cartridge is recommendable. Each click adjustment moves the point of impact by 1 MOA (approximately 1"± at 100 yds, 1/2"± at 50 yards)

Elevation & Windage Adjustment

1. Release the locking screw with the allen wrench until loosen.

2. Adjust the elevation and windage to the zero position.

3. Tighten the locking screw until it's locked.



Notice

Feedback from some customers states that the sights are blurry or it shows double images.Please don't worry,It just need 3-5 minutes to preheat when you first time to use it.(Just turn on and let it stay for 3-5 minutes).Then it will show clearly.
If it still results the same, please do not hesitate to let us know before you low rating, we will try our best to help you out.

Warranty

Within 12 months of purchase: Return to our store for repair or replacement. This warranty does not cover normal wear and tear, modifications, misuse, disintegrations, negligence, accidents, improper maintenance, or repair by anyone other than an Authorized retailer.

Customer Service

www.facebook.com/Feoutdoor/
650-629-5312/650-629-5952
info@feyachi.com
www.feyachi.com

ABOUT US

committed to the development of cost-effective outdoor tactical equipment, in the pure of cost-effective while providing the highest quality customer service.