Rechargeable

FL Series Flashlight

User Manual

INSIDE THE BOX

FL Rechargeable flashlight

Tactical Pressure Switch

USB Charging Cable

Velcro Strap

Rail Mount Kit(Based on the model)

Hexagonal Wrench

Instruction Manual

SPECIFICATIONS

Material: AL6061-T6 Aluminum Alloy

Lumen value: 1500 lumen MAX

Waterproof rating: IPX7


Irradiation distance: 250 Meters

Duration of irradiation: 3 Hours

Charging time: 3-4 Hours

How to charge


Turn the head of the light around to reveal the charging port, and use the included charging cable to charge.




- Red light when charging
- Blue light when full

HOW TO OPERATE

Tail cap switch has two functions on/off and switching light modes, press it to turn on the flashlight, then press it again to switch light modes (there are four modes, high, medium, low, and strobe), and press it again to turn off the flashlight after fixing a mode for ten seconds.




Included pressure switch is easy to operate with one hand. It comes with a normally open push button switch (with both on/off and toggle light modes) and a momentary on-pressure switch, 2 modes to meet different tactical needs.




FLASHLIGHT RAIL MOUNT

The rail mount type you get base on the model you ordered.(FL31 FL32 FL34 FL37)


FL31 Contains a Picatinny 45 Degree Flashlight Ring Mount.




FL32 Contains a M-lok Flashlight Ring Mount.



FL34 Contains a ML87 M-lok Versatile Mounting Option Offset Flashlight Ring Mount.




FL37 Contains a M-lok 45 Degree Flashlight Ring Mount.




For customers who order the FL34, the included ML87 has detailed user manual as below:

Diverse Mounting Position


Forward Offset



Backward Offset




No Offset




Installation

1. choose one of the mount type. The below installation is based on the forward offset.


2. Connect the screws and nuts through the holes of the offset mount. Keep it loosen but connected.




3.Put the nuts into the M-lok rail then tighten the screws with the allen wrench.




4.Put the flashlight ring mount into the offset mount.




5.Tighten the screws with the allen wrench.



6.Put the flashlight though the ring mount. The 2 inserts are for different diameter flashlights.



7.Tighten the screws with the allen wrench.



DANGER

DO NOT throw the light directly into human eyes. This may cause temporary blindness, or permanent damage to the eyes. DO NOT immerse the flashlight to water.

WARRANTY

Within 30 days of purchase: Return to retailer from which you purchased for repair or replacement.

Within 1 years of purchase: Return to our store for repair or replacement. This warranty does not cover normal wear and tear, modifications, misuse disintegrations, negligence, accidents, improper maintenance, of repair by anyone other than an Authorized retailer or ourselves.

CUSTOMER SERVICE

info@feyachi.com

www.feyachi.com

www.facebook.com/feoutdoor