Feyachi®

Reflex Sight

RS-38 User Manual


Specification

Magnification	1x
Objective aperture	33mm
Field of View	15.8@ 100m
Windage/Elevation Click Value	1 MOA per Click
Adj. Range	+/- 30 MOA
Eye Relief	Unlimited
Length	82mm
Battery	1xCR2032
Weight	4 oz
Size	3.2″ x 1.5″ x 2.1″
Shake Awake	8 minutes later

Inside the box


1 x 4 Reticles Reflex Sight
1 x Rubber lens Cap Cover
2 x CR 2032 Battery
1 x Cleaning Cloth
2 x Wrenches

Diagram




How To Use?

1. Install the battery
Place the CR2032 battery into the battery compartment.




2. Turn on the reflex sight
Press the switch to power up the sight to the last used brightness intensity. Press again to adjust the brightness. Press and hold for two seconds to close.

The left button is red light.
The right button is green light.




3. Select the reticle
Dial the reticle selector knob to switch the reticle pattern.



4. Motion Awake
After 8 minutes of inactivity, the red dot sight will enter sleep mode. Slightly shake to wake up the red dot.

5. Power Off
Press and hold for 3 seconds to turn off.




Zeroing

Select the reticle you desire by turning the reticle selector knob and setting your intensity at the best position. With the sight mounted, rest the equipment on a solid support and aim at a target 50 to 100 yards away. Test shots should be done in the same conditions to achieve maximum accuracy for adjustment, for which the use of equipment rest for firing is recommendable. Each click adjustment moves the point of impact by 1 MOA (approximately 1"± at 100 yds, 1/2"± at 50 yards)

Elevation & Windage Adjustment

1. Release the locking screw with the allen wrench until loosen.
2. Adjust the elevation and windage to the zero position.
3. Tighten the locking screw until it's locked.



Notice

Feedback from some customers states that the sights are blurry or it shows double images. Please don't worry, it just needs 3-5 minutes to preheat when you first use it. (Just turn it on and let it stay for 3-5 minutes). Then it will show clearly.

If it still results in the same, please do not hesitate to let us know before you low rating, we will try our best to help you out.

Warranty

Within 12 months of purchase: Return to Feyachi for repair or replacement. This warranty does not cover normal wear and tear, modifications, misuse, disintegrations, negligence, accidents, improper maintenance, or repair by anyone other than an Authorized retailer or Feyachi itself.

Contact

info@feyachi.com
www.feyachi.com
www.facebook.com/Feoutdoor
(1)877-734-1687

ABOUT US

Feyachi committed to the development of cost-effective outdoor tactical equipment, in the pure of cost-effective while providing the highest quality customer service.

Operating Instructions

For optimum performance and to prevent damage to this precision instrument, carefully follow all instructions.