

# User Manual

Laser Flashlight

## To every buyer

1. Thank you very much for choosing Feyachi product. This product is a combination of laser plus flashlight, with 4 work modes: laser only, LED and laser, LED only, LED strobe.
2. We have added a slider to the flashlight. You can adjust the position of the slider by holding down Quick Release Screws, so that it can apply other different equipment, very convenient.
3. Moreover, Press the battery pop up button to pop out the battery, which is convenient to take out for charging.
4. This product is suitable for mounting to handguns, rifles, shotguns or equipment with picatinny attachment rails.
5. With 2 laser colors (red and green) options for Feyachi laser light, either will be a perfect choice for you.

## Inside the box



1x Laser Flashlight




1x User Manual



2x Small Wrenchs



1x Tyce-C Charging cable


## Product size





## Specifications

| | |
|---|---|
| Product Name: | Laser Flashlight Combo |
| Housing Material: | Aluminum Alloy |
| Brightness: | 700LM(Lumens decrease over time) |
| Laser Wavelength: | (Red)650nm (Green)520nm |
| Laser Power: | <5mW |
| Laser Operating Current: | (Green)150-170mA (Red)20-30mA |
| Laser Range: | >100m (Indoor) |
| LED Color Temperature: | 6500-7000K |
| Battery Type: | 700 mAH Rechargeable Polymer Battery |
| Charging Current: | 350mA |
| Charging Time: | 2.5 Hours |
| Product Weight: | 97g(Batteries included) |
| Waterproof Rating: | IP53 |

## Button introduction





## How to install it on the guide rail?




By holding this button, the slider can be adjusted by sliding up and down to adjust the position. The function of quick installation and practicality is achieved at the same time.

After adjusting the slider, press the Quick Release Screws, align the Picatini rail card slot, and release quick release screws.

## Charging indicator





- Red Indicator light means charging.
- Green Indicator light means full charge.

## Introduction to use

Press power switch once to turn on or off.
Four operating modes need to be operated with the power switch turned on.
No matter in which mode, press the Power switch again to turn it off.

**[ Flashlight Strobe ]**
Press the power switch twice.




**[ Laser Only ]**
Flatten the mode switch button on the left.

**[ Flashlight+Laser ]**
Keep the Mode Toggle button in the center position.

**[ Flashlight Only ]**
Flatten the mode switch button on the right.

## Precautions before use:

1. Press this button and the battery will pop up.
2. Please remove the insulating paper from the battery and start using the laser light.



## Danger

DO NOT throw the light or laser directly into human eyes. This may cause temporary blindness, or permanent damage to the eyes.
DO NOT cover the light head when the flashlight is on, or place the light head on the ground. The radiation energy of the light may cause damage to the flashlight itself, or even result in burning to flammable objects.
DO NOT immerse the flashlight to water.

## Warranty

Within 30 days of purchase: Return to retailer from which you purchased for Refund or replacement.
Within 1 years of purchase: Return to retailer from which you purchased for repair or replacement.
This warranty does not cover normal wear and tear, modifications, misuse, disintegrations, negligence, accidents, improper maintenance, or repair by anyone other than an Authorized retailer.